

Wire Free Victorian Bell Kit

SX-60i

1

Remove Isolation Strip

CR2032 3V Lithium Battery

Push Button

- Open up the push button by pushing in the tab on the bottom of the push with a small flat screwdriver.
- Remove the isolation strip from the battery compartment then it is ready to use.
- When replacing the battery, ensure the battery polarity matches the internal markings ("+" facing upwards), then press the battery down so that it is sitting firmly in its compartment.

2

Victorian Bell

Insert 4 x 1.5volt alkaline batteries ("C", UM2 & LR14 - not included) into the battery compartment at the back of the Bell unit, ensuring the battery polarity matches the internal markings.

IMPORTANT: NOT TO BE USED WITH A TRANSFORMER

3

Digital Code Set Up

- Press the Push Button once, a new operation code is generated randomly and sent to the Chime unit.
- The Bell unit will sound to indicate that a new operation code is registered and memorised.

4

Push Button Installation

- Using the holes on the back of push button as a template, mark the fixing position for the unit.
- Drill holes and fit wall plugs and secure the push button unit to the wall with screws.
- Do not mount it on any metal surface or UPVC door frame.

Metal surface
UPVC Door-frames
IP44
+40°C
-10°C

5

Door Chime Installation

- Drill two holes, fit a wall plugs and screws.
- Leave a gap of 3mm between the screw head and wall.
- Locate the keyhole slots on the back of the chime unit over the screws.

Metal surface
UPVC Door-frames
Indoor use only
+40°C
-10°C

6

Operation

- Press the button on the Push Button unit once, it sends a wireless signal to the Bell unit, the Bell unit will sound.
- Operate the Bell unit within the operation range, test it before final installation.

Important:

- Make sure new set of alkaline battery is used in first time operation.
- Make sure the batteries are installed properly and the battery polarities match the internal markings.
- Change the frequency digital codes if door chime activate intermittently for no reason at all (see digital set up).
- Do not use the Chime unit with transformer

Wire Free Victorian Bell Kit

SX-60i

Push Button unit

Power: 1 x 3volt Lithium battery (CR2032 - included)

Door Chime unit

Power: 4 x 1.5volt alkaline batteries ("C", UM2 & R14 - not included)

Door Chime Operation

Press the button on the Push Button once, it sends a wireless signal to the Victorian Bell unit and it will sound. For repeat sound, press the button again. Hold the button in will **NOT** repeat the sound.

Digital Code Set Up

The Victorian Bell kit is equipped with an advanced random and self-learning operation coding ability therefore no setting is needed. Read the following instructions before use.

1. First time operation:

After battery installation on the Push Button and Victorian Bell units, press the Push Button once and it will generate a new operation code randomly and send a wireless signal to the Victorian Bell unit. The Bell unit will sound to indicate that a new operation code is registered and memorised.

2. Interference from a similar unit operating nearby:

- Simply remove the batteries from the Push Button and Victorian Bell units and rest for 10 seconds, this will erase the memory.
- Insert the batteries into the Push Button and Victorian Bell units. Press the Push Button once, it will generate a new operation code randomly and send a wireless signal to the Victorian Bell and it will sound to indicate that a new operation code is registered and memorised.

3. Front and back door Push Button operation:

- Remove the batteries from the Push Buttons (Front & Back Door) and Victorian Bell units and rest for 10 seconds, this will erase the memory.
- Insert the batteries into the Push Buttons and Victorian Bell units. Press the front door Push Button once, it will generate a new operation code randomly and send a wireless signal to the Victorian Bell unit and it will sound to indicate that a new operation code is registered and memorised.
- After, (within 2 minutes) press the back door Push Button once, it will generate a new operation code randomly and send a wireless signal to the Victorian Bell unit and it will sound to indicate that a new operation code is registered and memorised. The Victorian Bell unit has the ability to memorise both operation codes.
- Test to ensure correct operation before final installation.

Important

- Do not mount either unit close to fireplace or expose to high temperatures.
- Do not expose the Victorian Bell unit to direct sunlight or moisture
- Always use alkaline battery. Please dispose of old, defective batteries in an environmentally friendly manner in accordance with the relevant legislation.
- Make sure that no naked flame sources, such as lighted candles, should be placed on the unit.
- The unit should not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should be placed on the unit.

- CAUTION:** Replace only with the same or equivalent type of battery that is recommended by the manufacturer.
- CAUTION:** Make sure batteries are installed correctly as per the internal markings.
- CAUTION:** Danger of explosion if battery is incorrectly installed or replaced.
- IMPORTANT:** There are no serviceable parts in the units, do not attempt to repair it.

User Hints

If the Bell unit does not sound, please check the following:

- Flat batteries in either Push Button or Victorian Bell units - change the batteries.
- Wrong battery polarity in either Push Button or Victorian Bell units - re-insert the batteries.
- Push Button and Victorian Bell units are not on the same operation codes - re-set the code (see digital code set up).
- Units are out of range - Operate the Victorian Bell unit within the operation range.

Specification

Operating Temperature: -10C - +40C

Operating Distance: 100metre (330ft approx. - in open field & at suitable condition)

Selectable Digital Code: Total two hundred fifty six (256) possible digital codes

"Type R2 Device - device where the sound output is created by the initial operation of the control and where the period of sound output continues for the designed duration irrespective of condition of the control."

CH Byron Electrical Ltd
Byron House
34 Sherwood Rd, Astonfield
Bromsgrove, B60 3DR
UK
Tel: 0845 2301231
e: support@chbyron.com
w: www.chbyron.com



Byron		433MHz	
R&TTE APPROVED		CE0681	
A	✓	IRL	✓
B	✓	T	✓
DK	✓	L	✓
F	✓	NL	✓
D	✓	E	✓
GR	✓	S	✓
LT	✓		
UK	✓	M	✓
BG	✓	N	✓
CZ	✓	SK	✓
EST	✓	SLO	✓
H	✓	CH	✓
IS	✓	PL	✓
LV	✓	RO	✓

CH Byron Electrical United Kingdom. www.chbyron.com